




## GLIDER COT INSTRUCTION MANUAL

**IMPORTANT! KEEP FOR FUTURE REFERENCE.**


### INSTRUCTIONS FOR ASSEMBLY AND USE



Due to variation on the styles and designs of our products, the photographs and illustrations shown in this manual are generic. Therefore products fabric, colour and design may vary from images shown, chelino reserves the right to alter products specifications.

**FOR THE SAFETY OF YOUR CHILD, PLEASE READ THESE INSTRUCTIONS BEFORE USING THE PRODUCTS.**


## STANDARD CONFIGURATION PARTS



A




B



C



D



E




F

A. Right frame module  
B. Left frame module

C. Cradle support base  
D. Bottom frame crossing tubes


E. Cradle module  
F. Power Adapter

## Remote control function (Selective)




## ASSEMBLY


1. As shown in the figure, open the left and right frame modules, until you hear a "click" sound indicating that it is pulled apart in place.




2. Assemble the bottom frame crossing tubes as shown in below figure, (pls attention right and left frame modules face inward as below figure ) Until the "click" sound indicates it is installed in place.




3. As shown in the figure, align the pipe orifices on the cradle module and insert them into the hanging tubes on the left and right frame module accordingly. Until "click" sound is heard, it means it is installed in place.



4. Unfold the cradle basket, open the zipper of the basket cloth cover, remove the inner fabric lining of the cradle basket, push the metal wires clip into the plastic holder on two sides. Then install the inner fabric lining and zip up the zipper. Unfold the canopy.




5.Put the cradle basket onto the frame. Align the two sides and insert into the plastic house on the cradle support base.Until "click" sound is heard, it means it is installed in place.



## FUNCTIONS


1. The canopy of the cradle hood is foldable.

Press inside buttons at two sides at same time to pull backward to fold the canopy.



2. Can be used as baby carrycot.


Press the plastic buttons at each side at same time to release the cradle basket upward, then it is a baby carrycot.



## **Battery assembly Battery Size: 1.5V 4\*AA/LR6 (Not Included )**

Install batteries if you need to use this swing away from an outlet.

We recommend using Alkaline batteries for longer battery life.



\*Loosen the screw in the battery compartment door with a screwdriver (not included) and remove the battery compartment door.


\*Insert four AA(LR6) alkaline batteries into the battery compartment.

\*Replace the battery compartment door and tighten the screws.

Note: Low battery power may cause product movement to slow, sound and lights to become faint or product to turn off all together. If this should happen, use the AC adaptor as a power source or replace the batteries. Replace the batteries with four alkaline AA (LR6) batteries.

\*If this product begins to operate erratically, you may need to reset the electronics. Turn the power off and then back on.

## **Swing control plate instructions**



Power on/off: Press button, the cradle connects with power, and power light turns on.

Music button: 12 melody, press first time, music turn on with low volume.

Speed button: 5 speeds, each speed has a speed light. press the button to start from 1st speed, press again for 2nd speed.. (press once again when swing in fifth speed, it then stop swing.)

Timer button: 3 timers, 15 mins, 30 mins, and 60mins. press button to move to the next timer. Each timer has a timer light. press second time, same music with middle volume, press third time, same music with high volume. press fourth time, music turn off. press five time, next music turn on with low volume, then repeat.

Speed button: 5 speeds, each speed has a speed number. press the button to start from 1st speed, press again for 2nd speed.. (press once again when swing in fifth speed, it then stop swing.)

Timer button: 3 timers, 15 mins, 30 mins, and 60mins. Choose one timer, the cradle will stop automatically to save power.

Digital display: Press speed button showing 5 speeds, press timer button showing three timers.

## Maintenance suggestion

- The mattress cover and fabric lining are removable and washable.
- Disassembly and assembly of this product can only be completed by adults. Please take care not to damage this product during disassembly and assembly.
- If there is any damage to the components of this product, please do not use this product again, and place this product away from children.
- When washing mattress cover and fabric lining, do not use dissolvable and corrosive articles.
- Note: the picture is for reference only. Please refer to the real object.

## ⚠ WARNING

- DO NOT use this product without reading the instructions for use first.
- Placing additional items in the product may cause suffocation.
- DO NOT use if any part is broken, torn or missing. Contact Chelino baby for replacement parts and instructional literature if needed.
- DO NOT substitute parts. Only use substitute parts provided or confirmed by the manufacturer.
- Please do not use any accessories that are not included in the product.
- Please make sure that all accessories of this product are not damaged during the transportation before assembling. If any accessories are damaged, keep it away from children and ensure proper use of the product.
- Please keep this product away from any source of fire and heat, including heating electrical appliances, gas fire, and so on.
- Please carefully check whether the product is completely fixed, and ensuring that all fixtures are properly installed before using this product.
- This product is suitable for a child who cannot sit up unaided; Please stop using the product immediately when the child can sit, kneel or push the product.
- The distance between the mattress and the top part of the bed no less than 20CM, and only one mattress can be used in this product.
- Please make sure the new mattress matches this product if you need to buy a separate mattress.
- Use mattress with suitable thickness according to the internal mark within this product.
- Do not place any objects in the bed that may reduce its internal depth.
- Do not place the product close to another product, which could present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords, etc.
- When using this product, please do not adjust the product and change the position of the product.
- Only use on a firm ground which is horizontal, level and dry.
- It's not allowed for more than one child to use this product at the same time.
- Do not let other children play unattended near the carry cot and stand.
- Do not leave flexible carrying handles inside the carry cot

PLEASE READ CAREFULLY AND FOLLOW THE FOLLOWING DIRECTIONS & WARNINGS  
RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE AND FUTURE USERS

## ⚠ **WARNING**

NEVER LEAVE CHILD UNATTENDED, ALWAYS KEEP CHILD IN VIEW, EVEN WHEN CHILD IS SLEEPING.

### INFANT CAN SUFFOCATE:

In gaps between a mattress too small or too thick and product side.

Never add a mattress, pillow, comforter, or padding. Use only the mattress provided by manufacturer. Never use a water mattress with this product.


### ATTENTION

- Only installation by adult is allowed. Children are prohibited.
- The crib/cradle should be placed on a horizontal floor.
- Young children should not be allowed to play unsupervised in the vicinity of a crib/cradle.
- The crib/cradle should be locked in the fixed position when a child is unsupervised in it.
- Never use the crib/cradle if any part is broken, for or missing.
- When a child is able to sit, kneel or to pull itself up, the crib/cradle shall not be used anymore for this child.
- All assembly fitting should always be tightened properly and that care should be taken that no screws are loose, because a child could trap parts of the body or clothing (e.g. strings, necklaces, ribbons for babies dummies, etc.) , which would pose a risk of strangulation.
- Never use the body of a cradle without its frame.
- The thickness of the mattress chosen shall be such that the internal vertical height (surface of the top of the mattress to the upper edge of the bed sides) is at least 200 mm in the highest position of the bed base.
- Concerning the size of the mattress when not sold with the crib/cradle.
- To be aware of the risk of open fires and other sources of strong heat, such as electric barfires, gas fires, etc in the near vicinity of the crib/cradle.
- Do not use when the child can sit or kneel or pull itself up.
- Do not close the fire, please use it under adults supervision. No jumping on the bed.
- The identification of specific carry cots that are suitable for use with the stand.
- The handles and the bottom of the carry cot should be inspected regularly for signs of damage and wear.
- It shall be checked that the stand is of the appropriate size to accommodate the base of the carry cot.
- Before carrying or lifting, make sure that the handle is in the correct position of use. The head of the child in the carry cot should never be lower than the body of the child. When the stand is not in use, it shall be stored away from children.
- The suitable size of the stand for the carry cot is L70 × W65 × H66.
- The suitable size of the carry cot for the stand is L83 × W41 × H26.
- The carry cot should be used together with the stand.

### CARE

- Disassembly and assembly of this product can only be completed by adults.
- Please do not damage product during the process of disassembly and assembly.
- If the product is damaged, please do not use it and keep the product away from the children.
- When washing mattress cover the fabric lining, don't use dissolved and corrosive articles.

## DIMENSION INFO



---

|        |         |               |       |
|--------|---------|---------------|-------|
| LENGTH | 83 CM   | CARTON LENGTH | 42 CM |
| WIDTH  | 61.5 CM | CARTON WIDTH  | 22 CM |
| HEIGHT | 97 CM   | CARTON HEIGHT | 84 CM |
| WEIGHT |         | 8 KGS         |       |

---

## ***SAFETY HINTS | INSTRUCTIONS OF USE | WARRANTY & GUARANTEE GUIDELINES***

1. Please read this User Guide thoroughly before using this product. If you are not sure on any point in this guide please consult with the sales person whom sold you this product or contact Chelino on 0118352520. Our offices hours are Monday to Thursday from 9:00 am to 13:00 pm and 14:00 pm to 16:30 pm and Fridays from 9:00 am to 12:00 pm and 14:00 pm to 16:30 pm. Our offices are closed on Saturdays, Sundays, Public holidays and for three weeks during the December/ January festive season. We are situated at 12 Kimberlite Road, Theta Ext, Booysens Reserve, 2091, Johannesburg, Gauteng, RSA.

2. To avoid suffocation or swallowing or any other illness, please keep all packaging which have been removed from parts wrapped in the box away from infants, toddlers, children or any other living being. Please carefully dispose of the unwanted packaging once this product is fully assembled and you are satisfied with your purchase.

3. Please make sure that you are entirely satisfied with your purchase before removing the warning card attached to this product and before using this product. Once the warning card has been removed and if this product has been used we will not accept the return of this product.

4. If you are not entirely satisfied with this product purchased, please disassemble this product and re-pack it in the original packaging and return it to the store you purchased it from together with the proof of purchase. Depending on the stores policy, you will either be entitled to a replacement product, a credit voucher or a refund. This depends on the stores policies.

5. If you are not entirely satisfied with the assemble of this product or if you are not 100% sure that you have assembled this product correctly, please take this product back to the store you purchased it from and request for some assistance in checking if the assembly is correct or get this product assembled. Depending on the store's policy, there could be an extra charge for this service. Chelino will not take any responsibility if this product is incorrectly assembled thus causing any sort of injury to the user or the child. Alternatively you can contact Chelino directly on 0118352520, our offices hours are Monday to Thursday from 9:00 am to 13:00 pm and 14:00 to 16:30 pm and Fridays from 9:00 am to 12:00 pm and 14:00 pm to 16:30 pm. Our offices are closed on Saturdays, Sundays, Public holidays and for three weeks during the December/ January festive season. There is a charge for the assembly of any product. If you require a Chelino representative to assemble this product you will have to bring this product to our offices which are situated at 12 Kimberlite Road, Theta Ext, Booysens Reserve, 2091, Johannesburg, Gauteng, RSA.

6. Please note, that any repair which will needs to be made to this product must be done at the Chelino workshop which is situated at 12 Kimberlite Road, Theta Ext, Booysens Reserve, 2091, Johannesburg, Gauteng, RSA. Our offices hours are Monday to Thursday from 9:00 am to 13:00 pm and 14:00 pm to 16:30 pm and Fridays from 9:00 am to 12:00 pm and 14:00 pm to 16:30 pm. Our offices are closed on Saturdays, Sundays, Public holidays and for three weeks during the December/ January festive season. We do not provide any loan\courtesy products while your product has been sent in for repairs. Chelino requires 7 working days to repair any product, but this lead time may vary depending on the transportation of the product too and from yourself. Once the warranty card is detached from this product and once this product is used even if used once and if there is a fault, this product will need to be sent to the Chelino Workshop for the repair and no refund\credit\exchange will be allowed. Only a Chelino representative can decide whether the product needs to be replaced\credited\exchanged.

7. Once you are satisfied with the assembly of this product and have read this instruction and agree to the terms stated and are ready to use this product, please ensure that all safety locks are engaged to ensure safe use of this product.

8. Please ensure that the child is always securely strapped into this product at all times. The seat belts must be properly adjusted to keep the child secured. If the seat belt is too loose the child could fall out thus causing injury. If the seat belts are too tight it will cause injury and aggravation to the child.

9. Never leave the child unattended or without parent\guardian supervision while in this product, as injury could be caused by other parties intentionally or unintentionally. This product can be knocked over and the child can be injured.

10. Please ensure that you use a new set of batteries. Never use one new and one old battery or mixed match batteries. This can cause the electronics to malfunction and there is no warranty on the electronic parts.

11. Never use this product for longer than one hour. It could cause the motor to malfunction.

12. Never allow the child to stand on the seat of this product. This can cause damage to the product and thus causing injury to the child. The child can also fall out of this product causing injury to him\herself. This can also cause damage to structure of this product.

13. This product is designed for the use of only one child. This product cannot accommodate more than one child.

14. Take special care when adjusting the backrest if the child is seated in this product. It is preferred to select the desired backrest position before seating the child this product.

15. Prevent and do not allow any child to climb into this product or hang onto the handle bars or any other part of this product. This imbalance of weight can cause this product to topple thus causing injury.

16. Storage trays\storage compartments\cup holders are there for convenience and are not suitable for holding large amounts of liquids (hot or cold) or heavy objects. These areas are also not waterproof or leak proof and spillage can occur.

17. This product is fit to carry a child weighing no more than 9kgs.

18. Chelino takes no responsibility and will not be held liable for any damage or injury caused by using this product or if this product is used for any other purposes other than its intended purpose.

Please note, there are no warranties or guarantee on any fabrics or sponge grip handles used on this product.



**Stores:** ChelinoBaby – Ormonde – JHB  
ChelinoBaby – Fourways – JHB  
ChelinoBaby – Greenstone – JHB  
ChelinoBaby – Menlyn – Pretoria  
ChelinoBaby – Kolonnade – Pretoria  
ChelinoBaby – Centurion – Pretoria  
ChelinoBaby – Gateway – Durban  
ChelinoBaby – Online – [www.chelinobaby.co.za](http://www.chelinobaby.co.za)



**Imported for :**

**ChelinoBaby Group of Companies.**

**No. 12 Kimberlite Road , Theta Ext 5 , Booysens Reserve , JHB , 2091. SA.**

**Tel: +2711 8352520**

**Info: [info@chelino.co.za](mailto:info@chelino.co.za)**